




INSTALLATION GUIDE FOR A60 MARINE DOORS BY WELDING









- 1. Check the dimensions of bulkhead opening according to door L-counterframe and drawings;
- 2. Check that bulkhead have cuttings for the possible fittings for locks, indication switches, door closers and other hardware;
- 3. Check the straightness of bulkhead;
- 4. Clean the bulkhead opening if needed (grinding tools);
- 5. Lift the L-counterframe to bulkhead opening;
- 6. Check the clearances, diagonal dimension and vertical straightness;
- 7. Weld the upper corners of counterframe No 1 and 2 according drawing 1 and 1.1.






STEEL PROFILE DOORS / METAL DOORS / MARINE DOORS









Drawing 1.1

Drawing 1.2

- 8. Check the diagonal dimensions.
- 9. Weld lower corners of frame No 3 and 4 according to drawing 1 and 1.1.
- 10. Gap between the bulkhead can be up to 20mm, if needed use spacer plates for welding;
- 11. Check the vertical dimensions and clearance of L-counterframe;
- 12. Weld L-counterframe according to drawing 1, 1.1 and 1.2 with distance between the welding spots max 455 mm, length of welding stitches 50mm;
- 13. Weld L-counterframe sill part according to drawing 1. No 17 and 18 according to drawing 1.3. and No. 19 and 20 according to drawing 1.4.






Drawing 1.3


Drawing 1.4

- 14. Check the straightness and clearance of L-counterframe;
- 15. Fit the door frame without door leave to L-counterframe;
- 16. Check the straightness of door frame in L-counterframe;
- 17. Keeping frame straight, weld the points 1, 2, 3 according to drawing 2 and 2.1
- 18. Check the straightness of door frame in L-counterframe;






Drawing 2



Drawing 2.1



- 19. Install the door leaf on hinges;
 For double door install first active door leaf;
- 20. Keeping doorleaf on correct position in frame weld the point no 4 according to drawing 2 and 2.1;
- 21. Check the gaps between frame and door leaf lock side 5+/-2mm, hinge side 2+/-2mm;
- 22. For double-leaf doors install now passive door leaf;
- 23. Check the operation of locks and latches and adjust if needed;
- 24. Weld rest of the fixing points according to drawing 2 and 2.1 distance between the welding max 455mm;
- 25. Weld points 9 and 10 according to drawing 2.2.



Drawing 2.2

26. Check once again the gaps, door locks and latches operation.